

INSTRUCTION FOR DIGITAL COIN COUNTER

Looking for a smart coin counter jar? Well, here it is! This ingenious coin counter , electronically counts every coin as it slips through the slot, then sums up your total deposits and displays them on the easy-to-read LCD screen. Say goodbye to manual counting!

Features:

- large LCD
- Reset switch

Due to the continuing improvements, actual product may differ slightly from the product described herein.



Open the coin counter lid



Unscrew the battery compartment



Put 2 AA battery into the battery compartment



Reset switch



Insert coins into the coin counter slot

Before each use, inspect the general condition of the tool. Check for the loose screws, cracked or broken parts, and any other conditions that may affect its safe operation. If any abnormal condition is found, have the problem corrected before further use. Do not use if damaged in any way.

Problem	Possible Causes	Probable solutions
No reading on LCD	1. Check if there are any batteries in battery compartment. 2. Batteries are incorrectly placed in digital counting coin counter battery compartment or they are low power need to be replaced.	Check batteries and replace with new, fresh batteries if necessary, being careful as to positive/negative positions in battery compartment.
Incorrect reading	Incorrect way of inserting the coins into the slot.	1.Insert the coins into the slot vertically. 2. Do not retrieve the coins when inserts the coins into the slot. 3.Do not press the coins too quickly and hardly into the slot